

INSTRUCTION MANUAL

Knife Sharpener

Item	10996
------	-------



Warning!

Before you begin using your appliance, **PLEASE READ AND UNDERSTAND THIS DOCUMENT CAREFULLY** before installing, operating, maintaining, or servicing.

There are many important safety messages in this manual and on your appliance. Always read all safety messages.

Failure to do so can result in appliance failure, property damage, serious injury or death. Appliance failure, injury or property damage due to improper installation is not covered by warranty.

Stop!

DO NOT RETURN THIS PRODUCT TO THE STORE!

For questions or assistance with this product, call TRENTO Toll free: **1-833-487-3686** or visit the support section from our website, **www.trentoequipment.com**

Version: Revised - 06/09/2026




Table of Contents

Item 10996

Section	Page
General Information -----	3 - 4
Safety and Warranty -----	4 - 7
Technical Specifications -----	7
Installation -----	7 - 8
Operation -----	8
Maintenance -----	8
Notes -----	9 - 10
Warranty Registration -----	11

General Information

Omcan Manufacturing and Distributing Company Inc., Food Machinery of America, Inc. dba Omcan and Omcan Inc. are not responsible for any harm or injury caused due to any person's improper or negligent use of this equipment. The product shall only be operated by someone over the age of 18, of sound mind, and not under the influence of any drugs or alcohol, who has been trained in the correct operation of this machine, and is wearing authorized, proper safety clothing. Any modification to the machine voids any warranty, and may cause harm to individuals using the machine or in the vicinity of the machine while in operation.

CHECK PACKAGE UPON ARRIVAL

Upon receipt of an Omcan shipment please inspect for external damage. If no damage is evident on the external packaging, open carton to ensure all ordered items are within the box, and there is no concealed damage to the machine. If the package has suffered rough handling, bumps or damage (visible or concealed), please note it on the bill of lading before accepting the delivery and contact Omcan within 24 hours, so we may initiate a claim with the carrier. A detailed report on the extent of the damage caused to the machine must be filled out within three days, from the delivery date shown in the shipping documents. Omcan has no recourse for damaged products that were shipped collect or third party.

Before operating any equipment, always read and familiarize yourself with all operation and safety instructions.

Omcan would like to thank you for purchasing this machine. It's of the utmost importance to save these instructions for future reference. Also save the original box and packaging for shipping the equipment if servicing or returning of the machine is required.

Omcan Fabrication et distribution Compagnie Limitée et Food Machinery d'Amérique, dba Omcan et Omcan Inc. ne sont pas responsables de tout dommage ou blessure causé du fait que toute personne ait utilisé cet équipement de façon irrégulière. Le produit ne doit être exploité que par quelqu'un de plus de 18 ans, sain d'esprit, et pas sous l'influence d'une drogue ou d'alcool, qui a été formé pour utiliser cette machine correctement, et est vêtu de vêtements de sécurité appropriés. Toute modification de la machine annule toute garantie, et peut causer un préjudice à des personnes utilisant la machine ou des personnes à proximité de la machine pendant son fonctionnement.

VÉRIFIEZ LE COLIS DÈS RÉCEPTION

Dès réception d'une expédition d'Omcan veuillez inspecter pour dommages externes. Si aucun dommage n'est visible sur l'emballage externe, ouvrez le carton afin de s'assurer que tous les éléments commandés sont dans la boîte, et il n'y a aucun dommage dissimulé à la machine. Si le colis n'a subi aucune mauvaises manipulations, de bosses ou de dommages (visible ou cachée), notez-le sur le bon de livraison avant d'accepter la livraison et contactez Omcan dans les 24 heures qui suivent, pour que nous puissions engager une réclamation auprès du transporteur. Un rapport détaillé sur l'étendue des dommages causés à la machine doit être rempli dans un délai de trois jours, à compter de la date de livraison indiquée dans les documents d'expédition. Omcan n'a aucun droit de recours pour les produits endommagés qui ont été expédiés ou cueillis par un tiers transporteur.

General Information

Avant d'utiliser n'importe quel équipement, toujours lire et vous familiariser avec toutes les opérations et les consignes de sécurité.

Omcan voudrais vous remercier d'avoir choisi cette machine. Il est primordial de conserver ces instructions pour une référence ultérieure. Également conservez la boîte originale et l'emballage pour l'expédition de l'équipement si l'entretien ou le retour de la machine est nécessaire.

Omcan Empresa De Fabricacion Y Distribucion Inc. Y Maquinaria De Alimentos De America, Inc. dba Omcan y Omcan Inc. no son responsables de ningun daño o perjuicio causado por cualquier persona inadecuada o el uso descuidado de este equipo. El producto solo podra ser operado por una persona mayor de 18 años, en su sano juicio y no bajo alguna influencia de droga o alcohol, y que este ha sido entrenado en el correcto funcionamiento de esta máquina, y ésta usando ropa apropiada y autorizada. Cualquier modificación a la máquina anula la garantía y puede causar daños a las personas usando la máquina mientras esta en el funcionamiento.

REVISE EL PAQUETE A SU LLEGADA

Tras la recepcion de un envio Omcan favor inspeccionar daños externos. Si no hay daños evidentes en el empaque exterior, Habra el carton para asegurarse que todos los articulos solicitados estén dentro de la caja y no encuentre daños ocultos en la máquina. Si el paquete ha sufrido un manejo de poco cuidado, golpes o daños (visible o oculto) por favor anote en la factura antes de aceptar la entrega y contacte Omcan dentro de las 24 horas, de modo que podamos iniciar una reclamación con la compañía. Un informe detallado sobre los daños causados a la máquina debe ser llenado en el plazo de tres días, desde la fecha de entrega que se muestra en los documentos de envío. Omcan no tiene ningun recurso por productos dañados que se enviaron a recoger por terceros.

Antes de utilizar cualquier equipo, siempre lea y familiarizarse con todas las instrucciones de funcionamiento y seguridad.

Omcan le gustaría darle las gracias por la compra de esta máquina. Es de la mayor importancia para salvar estas instrucciones para futuras consultas. Además, guarda la caja original y el embalaje para el envío del equipo si servicio técnico o devolución de la máquina que se requiere.

Safety and Warranty

Carefully read the warnings contained in these instructions as they supply important indications regarding installation, use and maintenance safety for the Knife Sharpener.

This appliance is intended for household use.

This appliance must be used only for the purpose for which it was specifically designed, that is to sharpen blades. Any other use is to be considered improper and dangerous.

Safety and Warranty

Do not use this machine to sharpen serrated knives.

Children should not use the device as a toy and should neither clean nor use the equipment.

Keep children away from the device and from the power cord.

The appliance must be used by adults adequately trained for the purpose who have carefully read the contents of this manual.

The package elements (plastic bags, expanded foam, ect.) must not be left in the presence of children as it can cause a choking hazard.

Electrical safety of this appliance is assured only when it is correctly connected to an efficient grounding system as specified by current electrical safety standard.

The installation must be carried out according to these instructions. Incorrect installation can cause harm to people, animals or properties in respect of which Omcan can not be held responsible.

Omcan can not be held responsible for any damage caused by the lack of grounding of the system.

- Before plugging the appliance make sure that the data on the rating label corresponds to those of the electrical distribution network.
- The plate is on the bottom of the appliance.
- In case of incompatibility between the socket and plug of the appliance, have the die-casted cord and plug replaced with another one by an authorized dealer. In case of tampering Omcan cannot be held responsible either for safety or for warranty.
- Do not connect the appliance to the power supply via external timer or remote control systems.
- The use of any electrical appliance requires the observation of some basic rules. In particular:
 - Do not touch the appliance with wet hands.
 - Do not use the appliance barefooted.
 - Do not pull the power cord or the appliance itself to remove the plug from the socket.
 - Do not leave the appliance exposed to the elements (rain, sun, ect.).
 - Do not move the appliance while in use.
 - The appliance must not be submerged or sprayed with water or any other liquid.
- In case of failure or malfunction, turn it off and unplug it. For repairs apply only to Omcan or to a service center authorized by the same and require the use of genuine spare parts. Failure to comply with the above may compromise the security of the device.
- To avoid dangerous overheating, it is recommended to extend the power cord to it's full length and to use the appliance as recommended in the operation section of this manual.

During functioning, the outlet must be easily accessible in case it's necessary to disconnect the appliance. Do not place the appliance under a power socket so that the cord doesn't interfere with the machines correct use.

- Do not leave the appliance plugged in when not in use.

Safety and Warranty

- At the end of use always switch off and unplug from the socket.
- If the power cord is damaged, it must be replaced by Omcan.

Before performing any operation, turn the appliance off and disconnect the power plug from the power socket.

Do not wear loose-fitting clothes particularly with open sleeves; where necessary use suitable headgear to cover hair.

Make sure the power cord does not protrude from the floor to avoid a trip hazard.

Place the appliance on a flat and stable surface.

Do not place the appliance on or near heat sources.

Never immerse the appliance in water.

Do not use the appliance in environments containing explosive, combustible gases or flammable liquids. Danger of explosion or fire.

Do not remove the safety devices and do not modify or exclude the mechanical and electrical safety devices.

In case of problems with the appliance, contact Omcan. Do not attempt to repair the device yourself, any repair work carried out by an unauthorized individual will void the warranty.

Omcan is not responsible for any damage caused by improper use of this device resulting from:

- Failure to follow instruction contained in this manual.
- Use not in accordance with specific regulations, in force in the country of installation.
- Changes and unauthorized repairs.
- Use of accessories and not original spare parts.
- Misuse of the machine with different functions from what was intended.
- Incorrect installation.
- Failure to comply with the specific power techniques.
- Insufficient or incomplete periodic maintenance.
- Use by people under the age of 18.
- Use by people with physical, sensory or mental skills that are reduced.
- Exceeding the loading limits allowed by the machine.
- Use in non food based environments.
- Exceptional events.

1 YEAR PARTS AND LABOUR BENCH WARRANTY

Within the warranty period, contact Omcan Inc. at 1-800-465-0234 to schedule a drop off to either an Omcan authorized service depot in the area, or to an Omcan Service warehouse to repair the

Safety and Warranty

equipment.

Unauthorized maintenance will void the warranty. Warranty covers electrical and part failures, not improper use.

Please see <https://omcan.com/disclaimer> for complete info.

WARNING:

The packaging components are classified as normal solid urban waste and can therefore be disposed of without difficulty.

In any case, for suitable recycling, we suggest disposing of the products separately (differentiated waste) according to the current norms.

DO NOT DISCARD ANY PACKAGING MATERIALS IN THE ENVIRONMENT!

Technical Specifications

Item Number	10996
Electrical	115V / 60Hz
Overall Dimensions	8.3" x 8" x 6.2" / 210 x 203 x 157mm
Weight	9 lbs. / 4 kgs.

Installation

PACKAGING

Ensure that the packaging is fully intact, if this is not the case, please advise the courier or local dealer immediately.

In order to remove the unit from it's packaging, please proceed as follows:

- Open the box and remove the instruction booklet.
- Lift the machine with great care and place on a solid surface.
- Remove the plastic bag that wraps the unit.
- Check that all components specified on the delivery note are present and fully intact.
- Should any faults be noted, such as:
 - Dents.

Installation

- Controls that are either not working or broken.
- Missing items or other problems.

Please advise the courier, Omcan and service center immediately.

Carefully dispose of packaging components as required by the local standards.

DO NOT DISPERSE THE PACKAGING MATERIALS IN THE ENVIRONMENT.

Operation

CORRECT USE

The knife grinder is intended only for sharpening non-serrated knives. Serrated blades and blades without handles must not be sharpened.

USING THE MACHINE

- Wash the blades before grinding.
- Place the equipment on a well leveled, smooth, dry and stable surface.
- Turn the knob, located on the side, to adjust the distance of the grinding wheels, depending on whether there are knives with small or large blades. In this way, it is possible to adjust the angle of the sharpening.
- Place the blade between the two wheels and slide the blade.
- Slide the blade back and forth between the stones without pressing to obtain a professionally sharpened blade in a few seconds. The sharpening time depends on the wear of the knife edge.
- Repeat all of the previous operations on the next blade.
- Wash the blade after finishing the sharpening process.
- The motor can work for a maximum of 8-10 minutes, after this period of time, the motor must rest for 1 hour and 30 minutes in order to cool down.

Maintenance

The grinder does not require any special maintenance. To clean the machine body, use only a damp cloth. Do not spray with water.

Notes

[illegible]

This image shows a blank sheet of white paper with horizontal ruling lines. The lines are evenly spaced and run across the width of the page. There are no margins, text, or other markings on the paper.

Warranty Registration

Thank you for purchasing an Trento product. To register your warranty for this product, complete the information below, tear off the card at the perforation and then send to the address specified below. You can also register online by visiting:

Merci d'avoir acheté un produit Trento. Pour enregistrer votre garantie pour ce produit, complétez les informations ci-dessous, détachez la carte au niveau de la perforation, puis l'envoyer à l'adresse spécifiée ci-dessous. Vous pouvez également vous inscrire en ligne en visitant:

Gracias por comprar un producto Trento usted. Para registrar su garantía para este producto, complete la información a continuación, cortar la tarjeta en la perforación y luego enviarlo a la dirección indicada a continuación. También puede registrarse en línea en:

<https://omcan.com/warranty-registration/>

For mailing in Canada

Pour postale au Canada

Por correo en Canadá

TRENTO

PRODUCT WARRANTY REGISTRATION

3115 Pepper Mill Court,
Mississauga, Ontario
Canada, L5L 4X5

For mailing in the US

Pour diffusion aux États-Unis

Por correo en los EE.UU.

TRENTO

PRODUCT WARRANTY REGISTRATION

4450 Witmer Industrial Estates, Unit 4,
Niagara Falls, New York
USA, 14305

or email to: trentoservice@trentoequipment.com



Purchaser's Information

Name: _____

Address: _____

City: _____ Province or State: _____ Postal or Zip: _____

Country: _____

Dealer from which Purchased: _____

Dealer City: _____ Dealer Province or State: _____

Invoice: _____

Company Name: _____

Telephone: _____

Email Address: _____

Type of Company:

☐ Restaurant ☐ Bakery ☐ Deli

☐ Butcher ☐ Supermarket ☐ Caterer

☐ Institution (*specify*): _____

☐ Other (*specify*): _____

Model Name: _____ Model Number: _____

Serial Number: _____

Machine Description: _____

Date of Purchase (MM/DD/YYYY): _____

Date of Installation (MM/DD/YYYY): _____


Would you like to extend the warranty? ☐ Yes ☐ No

Thank you for choosing Trento | Merci d'avoir choisi Trento | Gracias por elegir Trento



TRENTO IS A SIGNATURE LINE OF PROFESSIONAL
RESTAURANT EQUIPMENT FROM OMCAN
OFFERING PREMIUM EUROPEAN BRANDS TO THE
NORTH AMERICAN MARKET.

Thank you for your purchase!



Follow us on social media
@trentoequipment



1-833-487-3686

 www.trentoequipment.com

 trentoservice@trentoequipment.com